

## Nitrite Test Kit-Tablet Count Method

### How to use:

A tablet is added to a 50ml or 100ml sample. The water sample develops a colour. More tablets are added until a colour change happens. The number of tablets used to force the colour change are entered into a simple formula to obtain the test result.

### Measurement-Range extendable by dilution:

Nitrite  
(70 - 1500 mg/l NaNO )

### Reagents:

Nitrite No. 1 (100 tabl.)  
Nitrite No. 2 (100 tabl.)

### Supplied with:

- Black plastic carrying case with foam insert
- 1 x 100ml shaker tube
- plastic stirring rod
- cleaning brush
- printed manual
- SVS2800 with 3 shaker tubes

